

# DI50097 - Reading Type

## Data Item Information

<b>Data Item Reference</b>	DI50097
<b>Item Description</b>	A code identifying the type of reading.
<b>Local Catalogue Reference</b>	J0171
<b>Data Item Owner</b>	Balancing and Settlement Code Company
<b>Logical Length</b>	1
<b>Decimal Length</b>	0.0
<b>Physical Length</b>	1
<b>Data Type</b>	String
<b>Data Type Format</b>	Edifact Level B DTS Variant
<b>Data Item Notes</b>	Value 'O' is only to be used in D0071 and D0300 flows.

## Data Item Enumeration

<b>Enumeration Value</b>	<b>Enumeration Description</b>
A	Actual Change of Supplier Read
C	Customer own read
D	Deemed (Settlement Registers) or Estimated (Non-Settlement Registers)
F	Final
I	Initial
M	MAR
O	Old Supplier's Estimated CoS Reading
P	Electronically collected via PPMIP
Q	Meter Reading modified manually by DC
R	Routine

S	Special
T	Proving Test Reading
<u>U</u>	<u>Forward Migration CoA</u>
<u>V</u>	<u>Forward Migration CoS</u>
W	Withdrawn
<u>X</u>	<u>Supplier Agreed Switch Read</u>
<u>Y</u>	<u>Reverse Migration CoS</u>
Z	Actual Change of Tenancy Read